



ITEM #	PART #	DESCRIPTION	ITEM #	PART #	DESCRIPTION	ITEM #	PART #	DESCRIPTION
101	316101	DEFLECTOR	143	315140	BUMBER COMBUSTION CHAMBER	318	315317	SELF TAPPING BOLT
102	315102	FILTER UNIT	144	315141	SAFETY SPRING	319	315316	BRACKET UNIT
103	315103	BOLT W/FLAT WASHER	145	315142	EXHAUST MESH PLATE	320	315318	SELF TAPPING BOLT
104	315105	COLLAR	146	315143	EXHAUST BAFFLE	321	316321	WIRE GUIDE B
105	315106	CAP	147	315144	HEX SOC. HD BOLT	322	316322	MOTOR CABLE
106	316106	HIGH VOLTAGE CABLE SET	148	315145	REED VALVE	323	315340	SELF TAPPING BOLT
107	315110	MOTOR UNIT	149	315146	CLEANER	324	315323	FLAT WASHER
108	315109	SPARKLER	150	316150	DEFLECTOR	325	315322	MOTOR FAN SWITCH LEVER UNIT
109	315112	HALF ROUND HD. HEX BOLT	151	315148	HEX SOC. HD BOLT	326	316326	PCB ASSEMBLY
110	315113	POSITIONING SHEET	152	315165	DRIVER GUIDE COVER	327	316327	CONNECTING UNIT
111	315114	GROUND WIRE BRACKET	153	315149	HEX SOC. HD BOLT	328	316328	INSULATING SLEEVE
112	315111	C RING	154	315150	BOLT ASSEMBLY	329	316329	LED COVER
113	315159	POSITIONING SHAFT	155	315164	DRIVER GUIDE	330	316330	HANDLE A UNIT
114	316114	FEED BUMPER	156	315157	SAFETY C (LEFT)	331	315330	FLAT WASHER
115	315166	SPACER	157	315161	SAFETY C (RIGHT)	332	315331	HEX SOC. HD BOLT
116	315160	C RING	158	315151	SAFETY B UNIT	333	315407	SPRING RETAINER
117	315115	SLEEVE MOTOR	159	315153	ADJUST AXIE UNIT	334	316334	POSITIONING AXIS
118	315116	WASHER MOTOR SHAFT	160	315152	SELF-LOCKING EXTERNAL NUTS	335	315405	HEX SOC. HD SCREW
119	315118	END CAP COMBUSTION CHAMBER	161	315154	SAFETY A	336	316336	SPRING RETAINER
120	315117	FUEL STEM ADAPTOR	162	315155	RING	337	316337	RAFT HOOK BRACKET
121	315119	O RING	163	315163	SAFETY SPRING	338	315403	BOLT CAP
122	315120	SEAL	164	315162	SAFETY ROD	401	316401	POSITIONING SHEET
123	315121	SEAL PLATE MOTOR	201	315201	SPRING	402	315402	HEX SOC. HD BOLT
124	315122	IN-CONCENTRIC RING	202	315202	TRIGGER	403	315404	HINGE POINT
125	315124	COOLING FAN ASSEMBLY	203	315203	SAFETY	404	315416	DRIVER GUIDE
126	315123	HEX SOC. HD SCREW	301	315301	GUN BODY	405	315417	SAFETY SPRING
127	315167	SPACER	302	315303	CAP NUT	406	315418	BOLT ASSEMBLY
128	315127	HEX SOC. HD BOLT	303	315302	WASHER CAP	407	315421	FIXED PIN
129	315125	HEX SOC. HD BOLT	304	316304	CYLINDER BRACKET	408	315422	MAGAZINE A
130	315126	GUIDE	305	315305	HEX SOC. HD BOLT	409	315423	DOOR LATCH
131	315128	UPPER COMBUSTION CHAMBER	306	315306	SAFETY COVER	410	315424	LATCH SPRING
132	315129	PACKING	307	315307	WASHER NOSE COVER	411	315425	DEEP IMPACT SOCKET 1
133	315132	COMBUSTION CHAMBER	308	315308	HEX SOC. HD BOLT	412	315426	PUSHER
134	315130	HEX SOC. HD BOLT	309	315309	PIN FUEL ACTUATOR	413	315427	SPRING
135	315131	WASHER	310	316310	FUEL ACTUATOR	414	316414	PU RETAINER
136	315133	PIN	311	315311	BUSH FUEL ACTUATOR	415	315429	MOUNTING BRACKET
137	315134	O RING	312	316312	TAP BOLT	416	316416	HEX SOC. HD BOLT
138	316138	C RING	313	316313	HANDLE A UNIT	417	316417	ATTACHMENT PLATE COVER A
139	315136	PISTON RING	314	315314	HANDLE BOLT	418	316418	ATTACHMENT PLATE COVER A
140	315137	DRIVER UNIT	315	316315	LOCK NUT	419	316419	TAP BOLT
141	315138	BUMBER	316	315312	LOCK NUT			
142	316142	CYLINDER	317	316317	SPACER			